


FRONT FORK SPRING KIT



YAMAHA XVS1300A MIDNIGHT STAR

▲ WARNING!

It is advisable to have an Öhlins dealer install the springs. Consult your vehicle service manual when installing this product.



- Put the motorcycle on a workstand so that the front wheel barely touches the ground.

▲ WARNING!

Make sure that the vehicle is securely supported so that it will not tip.


- Remove the instrument housing with bracket.
- Remove the clamps and gently fold the handle bar forward. Put a blanket on the headlight to protect the finish.
- Remove the top cap, original spacer, washer and fork spring. *Note! You will **not** need the original spacer, washer and spring for the installation of the Öhlins front fork spring.*
- Check the oil level and the quality of the oil (with the front fork fully compressed and no springs installed).

Recommended oil level: **110 mm**




- Install the Öhlins spring (*tighter wound coils to the top*), the spacer (if any; there are two options given here below) and finally the top cap (with the front fork fully extended).


6



Standard ride height



25 mm lowered ride height



- Reinstall all removed parts in the same way as before the installation.

Spring kit 08848-01 20070910

Öhlins Racing AB, Box 722,
S-194 27 Upplands Väsby, Sweden
Phone +46 8 590 025 00, Fax +46 8 590 025 80,
E-mail: info@ohlins.se, www.ohlins.com

Part no. 01200-05

