

Mounting instructions


HA 860 - Husqvarna 4-stroke

Kit contents

Shock absorber, Type 46PRC	HA 860	
Sticker Öhlins	00197-01	2
Sticker Memo note	01180-01	1
C-spanner	00710-02	1
Owners Manual		1

Set-up data

Length	449 mm
Stroke	125 mm
Rebound adjustment	16 clicks
Compression adjustment	15 clicks
Preload	13 mm



Adjusters

Your Öhlins shock absorber type 46 PRC features the following adjusters:

Compression damping:

Adjustments are made on top of the reservoir.

Rebound damping

Adjuster wheel on the piston shaft above the end bracket.

Spring preload

Adjustment made by screws on cylinder house.

Use C-spanner.

When delivered the Öhlins shock absorber is dialed to recommended settings for the specific brand and make of the motorcycle. If you have changed the setting check like this:

The adjusters have a normal right hand thread. Turn clockwise to fully closed. Turn counter clockwise to open and count the clicks until you reach the recommended number of clicks.

Do not use too much force, delicate sealing surfaces can be damaged. Do use fingers only.



ADVANCED SUSPENSION TECHNOLOGY

Öhlins Racing AB, Box 722, S-194 27 Upplands Väsby, Sweden.
Phone +46 8 590 025 00, fax +46 8 590 025 80.

E-mail: info@ohlins.se

www.ohlins.com

HA 860, ISSUED 01 03 22



ADVANCED SUSPENSION TECHNOLOGY

