Spring Preload Adjuster



Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.

Kit Contents

_		Part No.	PCS
	Shock Abs. 36E	HD 146	2
	C-Spanner twin	00710-01	2
	Sleeve	00123-13	2
	Sleeve	00123-17	2
	Washer	03118-08	8
	Sticker Öhlins	00192-01	2
	Owners manual	07241-02	1

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

▲ Warning!

Before installing this product, read the Öhlins Owner's Manual. The shock absorber is an important part of your vehicle and will affect the stability.

Shock Absorber for Harley-Davidson Sportster **HD 146**

Mounting Instructions



How to install

▲ Warning!

It is advisable to have an Öhlins dealer install the shock absorber.

When installing, consult your Vehicle Service Manual.

1

Put the motorcycle on a stand so the rear wheel is clear of the ground. Make sure it's steadily fixed so it will not fall over.

▲ Warning!

Make sure the vehicle is securely supported so that it will not tip.

2

Loosen and remove the standard shock absorber(s). See the motorcycles Workshop manual.

3

Fit the Öhlins shock absorber(s) in the same position as the standard shock absorber(s).

Note!

Before installing the Öhlins shock absorber clean the vehicle thoroughly.

л


Continue your work according to the Owners manual, section adjustment.

Note!


Lower the motorcycle so that the shock absorber is sligthly compressed, before tightening the screws.

Caution!

Make sure that all screws are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber when the suspension is fully compressed or extended.



Normaly the shock absorber is mounted with the cylinder head upwards. Check that there is enough clearence to other details both in loaded and unloaded position.



Checking sag and ride height

Front suspension

- F1. Bike on a stand with the suspension fully extended =
- F2. Bike on the ground without rider =
- F3. Bike on the ground with rider =

Free sag F1 - F2 =

Ride height $F1 - F3 = \dots$

Rear suspension

R1. Bike on a stand with the suspension fully extended =

R2. Bike on the ground without rider =

R3. Bike on the ground with rider =

Free sag R1 - R2 =

Ride height R1 - R3 =

NOTE!

If ride height is higher than recommended, softer spring/springs must be used. If ride height is lower than recommended, harder spring/springs must be used. Contact your Öhlins dealer for advice.

Adjustments

Warning!

Before riding, always make sure that the basic settings made by Öhlins are according to recommended Set-up Data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up the shock absorber.



Set-up Data

Re	com	mer	hahr	set-u	ın

Spring Preload

Spring

Part No. 00480-01 21 mm

Shock absorber data Length

Stroke

360,5 mm 105 mm

Rate

15-24 N/mm

Ohlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

To find the latest information contact your Öhlins distributor. Please consult your Öhlins dealer if you have any questions regarding the contents in this document.

Part no. HD146 1 Issued 2015-06-08

© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited.

Öhlins Racing AB Box 722 S-194 27 Upplands Väsby, Sweden Phone +46 8 590 025 00 fax +46 8 590 025 80

