



# MOUNTING INSTRUCTION

Brand	Type	Year	Code No	
<b>KTM</b>	<b>125 EXC</b>	<b>1995</b>	<b>KT 5131</b>	
Total length	Stroke	Rebound click	Compr. click	Preload
<b>445</b>	<b>130</b>	<b>17</b>	<b>22</b>	<b>12 mm</b>
Supplementary parts				
<b>197-01 Sticker/Dekal (2x)</b>				
<b>710-02 Hook spanner/Haknyckel</b>				
Mounting instructions				
				