



# MOUNTING INSTRUCTION

Brand	Type	Year	Code No	
<b>KTM</b>	<b>250/300 SX</b>	<b>1995</b>	<b>KT 5252</b>	
Total length	Stroke	Rebound click	Compr. click	Preload
<b>461,5</b>	<b>134</b>	<b>18</b>	<b>22</b>	<b>12 mm</b>

## Supplementary parts

- 197-01 Sticker/Dekal (2x)**
- 710-02 Hook spanner/Haknyckel**

## Mounting instructions

