WARNING!

The shock absorber is provided with a separate type reservoir filled with highpressure nitrogen gas. To prevent danger of explosion, study and make certain that you fully understand the following information before handling the shock absorber. The manufacturer cannot be held responsible for damage to property or personal injury that may result from improper handling.

1. Never tamper with or attempt to disassemble the cylinder or the reservoir.

2. Never expose the shock absorber to an open flame or other excessive heat. The shock absorber may othervise explode due to too high pressure.

3. Be careful not to damage any part of the gas reservoir. A damaged gas reservoir will impair the damping performance or cause malfunction.

4. Take care not to scratch the contact surface of the piston rod of the cylinder; oil could othervise leak out.

5. Never attempt to remove the plug at the bottom of the nitrogen gas reservoir. Any attempt to remove the plug implies serious danger.

6. When scrapping the shock absorber, follow the instructions for disposal.



If the shock absorber has an adjustable end eye/ bracket, this must not be treaded out more than that one groove is fully visible beneath the lock nut. Make sure that the lock nut is tightened after adjustment. Groove

Notes



SU003

Kit contents

Shock absorber Type 46HRCL	SU003	1
Owners manual		1
Sticker	0192-01	2
Mounting rubber	0230-01	2
Tie-rap	0231 -01	4
Hose clamp	0643-02	2
Hook spanner	0710-02	1
Sticker "Memo notes"	1180 -01	1

Set-up data

	Total length	312 +12 -0	mm
	Stroke	67	mm
	Preload spring	22	mm
J	Rebound adjustment	14	
	Compression adjustment	14	

Traction, handling, comfort and safety



ÄDVANCED SUSPENSION TECHNOLOGY Öhlins Racing AB, Box 722, S-194 27 Upplands Väsby, Sweden. Phone +46 8 590 025 00, fax +46 8 590 025 80. E-mail: info@ohlins.se SU003 Issued 990628



ADVANCED SUSPENSION TECHNOLOG

Safety signals

Important information concerning safety is distinguished in this manual by the following notations

A

The Safety alert symbol means: Caution! Your safety is involved.

A WARNING!

Failure to follow warning instructions could result in **severe or fatal injury** to anyone working with, inspecting or using the suspension, or to bystanders.

CAUTION!

Caution indicates that special precautions must be taken to avoid damage to the suspension.

NOTE!

This indicates information that is of importance with regard to procedures

Kit contents

Before installing the shock absorber, please check the contents of the kit, listed on the front page of this instruction. If anything is missing, contact your Öhlins dealer.

NOTE!

During storage and transportation, especially at high ambient temperature, the oil and grease used for assembling may run out inside the packing and damage the expanded polystyrene packing material. This is not unusual and is in no way detrimental to the shock absorber.

© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited. Printed in Sweden.

Before you start

A WARNING!

Installing a shock absorber, that is not approved by the vehicle manufacturer, may affect the stability of your vehicle. Öhlins Racing AB cannot be held responsible for any personal injury or damage whatsoever that may occur after fitting the shock absorber. Contact an Öhlins dealer or other qualified person for advice.

Öhlins Racing AB can not be held responsible for any damage whatsoever to shock absorber or vehicle, or injury to persons, if the instructions for fitting and maintenance are not followed exactly. Similarly, the warranty will become null and void if the instructions are not adhered to.

A:WARNING!

Please study and make certain that you fully understand all the mounting instructions and the owner's manuals before handling this shock absorber kit. If you have any questions regarding proper installation procedures, contact an Öhlins dealer or other qualified person.

A WARNING!

The vehicle service manual must be referred to when installing the Öhlins shock absorber.

NOTE!

Öhlins products are subject to continual improvement and development. Consequently, although these instructions include the most up-to-date information available at the time of printing, there may be minor differences between your suspension and this manual. Please consult your Öhlins dealer if you have any questions with regard to the contents of the manual.

Mounting Instructions

1

Remove the bottom of the fairing.

A WARNING!

1. It's advisable to have an Öhlins dealer or other qualified person to fit your shock absorber.

2. Instructions in the vehicle service manual are to be followed when changing the shock absorber.

3. When working on a lifted vehicle it must be securely supported to prevent it from falling.

1

Put the motorcycle on a stand so the rear wheel is clear of the ground. Make sure it's steadily fixed so it will not fall over.

3

Remove the seat and the side covers.

Loosen the battery box and plastic cover (only on 91years model).

5

Remove the bolt to the drag link and the two bolts that is holding the shock. Remove the shock absorber.

On this model is an adjustable end eye/ bracket mounted. The end eye/bracket must not be threaded out more than that the groove is visible beneath the locknut. See fig. Make sure that the locknut is tightened after adjustment.

6

Mounting of the Öhlin shock will start by pulling the reservoir upwards and out on the right side of the bike, see figure. Follow with the damper itself upwards and mount the upper bolt.

7

Mount the reservoir, see figure. (On 88-89 years model use mounting rubbers and hose clamps.)

8

Make sure that all boolts are tightened.

9

Mount the side covers, seat and fairing.

NOTE!

Make sure that all bolts are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber when the suspension is being fully compressed or extended.

WARNING!

Certain modifications may be necessary when installing the Ohlins shock absorber/suspension. It is essential that the mounting instructions are carefully followed.

Suzuki 750

