



MOUNTING INSTRUCTION

Brand TRIUMPH	Model TIGER	Year 93-96	Art. No. TR 539	
Total length 360,5 mm	Stroke 88 mm	Reb.click 16	Comp.click 15	Preload 8 mm

Supplementary parts

153-09 Washer / Bricka

192-01 Sticker / Dekal (2x)

231-01 Ty-rap / Buntband (4x)

710-02 Hookspanner / Haknyckel

1180-01 Memo sticker / Dekal

Owners manual / Instruktionsbok

Mounting instructions

- Lift the motorcycle and place it on a stand so that the rear wheel does not touch the floor.
- Remove seat, right side cover and both left side covers.
- Remove battery, left and right airbox and the battery box.
- Remove two tie straps holding the wire harness at rear fuel tank bracket.
- Remove rear fuel tank bracket, close the tap and loosen the fuel hose.
- Remove stock shockabsorber reservoir, i.e. compression adjuster.
- Loosen the bolt between the links and remove the lower shockabsorber bolt.
- Remove upper shockabsorber bolt and remove the shockabsorber, togheter with the hose and reservoir, downwards.
- Mounting the Öhlin-shockabsorber.
Start by pulling the reservoir from below, up and out on the left side. Put the shockabsorber in place with the hose connection pointing forwards. Mount upper shockabsorber bolt.
- Place the reservoir with compression adjuster in stock reservoir holder.
- Lower shockabsorber bolt has to be mounted with supplied Washer (153-09), nearest the bolt-head. Mount the bolt between the links.
- Mount the fuel hose and the rear fuel tank bracket. Fasten the wire harness with supplied tie straps.
- Mount the batterybox, left and right airbox and the battery.
- Mount right side cover, both left side covers and the seat.
- Make sure that all bolts are tightened.
- Palla upp MC:n på ett stöd så att bakhjulet hänger fritt.
- Demontera sadel, höger sidokåpa och de två vänstra sidokåporna.
- Demontera batteriet, vänster och höger luftbox och batteriboxen.
- Demontera två buntband som håller kabelstammen vid bakre tankfästet.
- Demontera bakre bränsletankfäste, stäng kranen och lossa slangen.
- Demontera standard stötdämparens behållare (kompressions justeringen).
- Lossa skruven mellan länkarna och demontera nedre stötdämparskruven.
- Demontera övre stötdämparskruven och för dämparen, slangen och behållaren nedåt.
- Montera av Öhlin-dämparen.
För behållaren underifrån och upp vidare ut på vänster sida, för samtidigt upp dämparen underifrån med slanganslutningen framåt. Montera övre stötdämparskruven.
- Placera behållaren med kompjusteringen på original behållarens plats.
- Nedre stötdämparskruven monteras med bifogad Bricka (153-09) närmast skruvskallen. Montera skruven mellan länkarna.
- Montera bränsleslang och tankfästet. Fäst kabelstammen med bifogade buntband.
- Montera batteriboxen, vänster och höger luftbox och batteriet.
- Montera höger sidokåpa, de två vänstra sidokåporna och sadel.
- Se till att samtliga skruvar är åtdragna.

Öhlins Racing AB fransäger sig allt ansvar för skada på stötdämpare, motorcykel eller person om inte monterings- och skötsel instruktionerna har följts till fullo. Ingen garanti kan ges på funktion eller livslängd om dessa instruktioner inte följts

Öhlins Racing AB can not be responsible for any damage to shock absorber, motorcycle or person if the mounting- and maintaining instructions are not followed exactly. Also no guarantee can be given for the performance and reliability if these instructions are not followed.