



MOUNTING INSTRUCTION

Brand YAMAHA	Model PW 50	Year	Art. No. YA 1350	
Total length 212 mm	Stroke 43 mm	Reb.click --	Comp.click --	Preload 2 mm

Supplementary parts

192-01 Sticker / Dekal "ÖHLINS" (2x)

Mounting instructions

1. Put the motorcycle on a stand so that the rear wheel is off the ground.
 2. Loosen the shock absorber mounting bolts and remove the stock shock absorbers.
 3. Note that one Öhlins shock absorber replace both stock shock absorbers.
 4. Mount the Öhlins shock absorbers on the drive shaft side, with the gas valve pointing rearwards.
 5. Make sure that all bolts are tightened.
1. Palla upp motorcykeln så att bakhjulet hänger fritt från golvet.
 2. Lossa stötdämparskruvarna och demontera original stötdämparna.
 3. OBS! En Öhlins stötdämpare ersätter båda original dämparna.
 4. Montera Öhlins-dämparen på kardanaxel sidan med gas ventilen bakåt.
 5. Se till att samtliga skruvar är åtdragna.

Öhlins Racing AB fransäger sig allt ansvar för skada på stötdämpare, motorcykel eller person om inte monterings- och skötsel instruktionerna har följts till fullo. Ingen garanti kan ges på funktion eller livslängd om dessa instruktioner inte följts

Öhlins Racing AB can not be responsible for any damage to shock absorber, motorcycle or person if the mounting- and maintaining instructions are not followed exactly. Also no guarantee can be given for the performance and reliability if these instructions are not followed.