

Setup data

Lenght	489 mm
Stroke	135 mm
Rebound adjustment	22 clicks
Compression adjustment	14 clicks
High speed comp. adj	2 turns
Free sag, rear	30±5 mm
Ride height, rear	90±5 mm
Front fork adjustment	std.
Recommended fork springs	std.

NOTE!

Make notes when the correct spring is mounted and sag and ride height is adjusted.

Spring pre-load____mm

Notes

Checking sag and ride height

Front suspension

i ioni suspension			
F1. Bike on a stand with the suspension fully extended	d		
suspension rully extended	u	=	 •
F2. Bike on the ground witho	<u>ut</u> rider	=	
F3. Bike on the ground with r	rider	=	
Free sag	F1 - F2	=	
Ride height	F1 - F3	=	
Ride height	F1 - F3	=	 -

Rear suspension

R1. Bike on a stand with the	
suspension fully extended	=

R2. Bike	on the	ground	without	rider	=	•

R3. Bike on the ground with rider

Free sag	R1 - R2 =

Ride height	R1 - R3 =
mue neigni	111 110 –

NOTE!

If ride height is higher than recommended, softer spring/springs must be used. If ride height is lower than recommended, harder spring/springs must be used. Contact your Öhlins dealer for advice.

HO 491, issued 04 04




Öhlins Racing AB, Box 722, S-194 27 Upplands Väsby, Sweden. Phone +46 8 590 025 00. Fax +46 8 590 025 80.

www.ohlins.com

Mounting Instructions

Öhlins shock absorber kit HO 491 for Honda CR 125 2004





Öhlins shock absorber 46 PRXW

compression adjustment

Your Öhlins shock absorber type 46 PRXW features the following adjusters:

Compression damping adjuster

Adjustments are made on top of the reservoir. Low speed adjustments: Slotted centre screw. High speed adjustments: Hexagon screw.

Rebound damping adjuster

Adjuster whell on the piston shaft above the end bracket.

Spring pre-load adjuster

Adjustment made by rings on cylinder house. Use C-spanner.

NOTE!

When delivered the Öhlins shock absorber is dialed to recommended settings for the specific brand and make of the motorcycle. If you have changed the settings, check like this:

The adjusters have a normal right hand thread. Turn the damping adjusters clockwise to fully closed (pos. zero [0]). Turn counter clockwise to open and count the clicks until you reach the recommended number of clicks. See Setup data at last page.

CAUTION!

Do not use too much force, delicate sealing surfaces can be damaged.

ADVANCED SUSPENSION TECHNOLOGY

Safety signals

Important information concerning safety is distinguished in this manual by the following notations:



The Safety alert symbol means: Caution! Your safety is involved.



Failure to follow warning instructions could result in **severe or fatal injury** to anyone working with, inspecting or using the suspension, or to bystanders.

CAUTION!

Caution indicates that special precautions must be taken to avoid damage to the suspension.

NOTE!

This indicates information that is of importance with regard to procedures.

Before installation

Öhlins Racing AB can not be held responsible for any damage whatsoever to shock absorber or vehicle, or injury to persons, if the instructions for fitting and maintenance are not followed exactly.

Similarly, the warranty will become null and void if the instructions are not adhered to.

A WARNING!

- 1. Installing a shock absorber, that is not approved by the vehicle manufacturer, may affect the stability of your vehicle. Öhlins Racing AB cannot be held responsible for any personal injury or damage whatsoever that may occur after fitting the shock absorber. Contact an Öhlins dealer or other qualified person for advice.
- Please study and make certain that you fully understand all the mounting instructions and the owners manuals before handling this shock absorber kit. If you have any questions regarding proper installation procedures, contact an Öhlins dealer or other qualified person.
- 3. The vehicle service manual must be referred to when installing the Öhlins shock absorber

Öhlins products are subject to continual improvement and development. Consequently, although these instructions include the most up-to-date information available at the time of printing, there may be minor differences between your suspension and this manual. Please consult your Öhlins dealer if you have any questions with regard to the contents of the manual.

NOTE!

During storage and transportation, especially at high ambient temperature, the oil and grease used for assembling may run out inside the packing and damage the expanded polystyrene packing material. This is not unusual and is in no way detrimental to the shock absorber.

Kit contents

Before installing the shock absorber, please check the contents of the kit, listed on the front page of this instruction. If anything is missing, contact your Öhlins dealer.

Description	Pcs.	Part No.
Shock absorber	1	HO 491
Washer	1	00543-01
Spring clip	1	00629-01
C-spanner	1	00710-02
Sticker Öhlins	2	00197-01
Sticker memo notes	1	01180-01
Owners manual	1	

Mounting instructions

1

Put the motorcycle on a stand so the rear wheel has ground clearance. Make sure it's steadily positioned and will not fall over.

A WARNING!

- 1. It's advisable to have an Öhlins dealer or other qualified person to fit your shock absorber.
- 2. Instructions in the vehicle service manual are to be followed when changing the shock absorber.
- 3. When working on a lifted vehicle it must be securely supported to prevent it from falling.

2

Remove the seat by loosening the rear attachment screws.

3

Loosen the rear frame and the hose clamp from the air filter. Disconnect electrical wires. Remove the whole unit with air filter and muffler. 4

Loosen the lower and the upper attachment of the original shock absorber and remove it.

5


Fit the Öhlins shock absorber in the same way as the original unit. Fasten it by using the two original screws.





6

Place the seat support and seat back in position and fasten them.



Make sure that all bolts are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber when the suspension is being fully compressed or extended.

7

Continue your work according to the Owners Manual, section Adjustments.